


KZ1300-A4 Wiring Diagram

(Except U.S., Canadian, U.K., West German, Swiss, and Swedish Models)



LEFT HANDLEBAR SWITCH CONNECTIONS													
Dimmer Switch		Automatic Turn Signal Cancel Switch			Turn Signal Switch				Horn Switch		Passing Switch		Release Switch
Bl	Br	BY	RY	Br	Y	R	Green	Orange	Gray	Blue	Red	Brown	Black
ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON	ON
LO	LO	LO	LO	LO	LO	LO	LO	LO	LO	LO	LO	LO	LO

IGNITION SWITCH CONNECTIONS					
Battery 1	Ignition	Tail 1	Tail 2	Battery 2	Tail 3
White	Brown	Blue	Red	Orange	Gray
OFF	OFF	OFF	OFF	OFF	OFF
ON	ON	ON	ON	ON	ON
PARK	PARK	PARK	PARK	PARK	PARK

RIGHT HANDLEBAR SWITCH CONNECTIONS					
Engine Stop Switch		Headlight Switch		Starter Switch	
Y/R	Br	Br/W	Brown	Bl	Black
OFF	OFF	OFF	OFF	OFF	OFF
RUN	RUN	RUN	RUN	RUN	RUN
OFF	OFF	ON	ON	ON	ON

MAIN SWITCH CONNECTIONS		
Battery	Ignition	Tail
Black	White	Black
OFF	OFF	OFF
ON	ON	ON
PARK	PARK	PARK